



• Back Road Equipment Slider Rear Rack Installation Instructions BMW F 800 GS

Tools Required:

5 mm hex wrench
¼” drill bit
21/64” drill bit
electric hand drill
marking pen
Torque wrench
5 mm hex drive socket

- Kit Contents:
- 1 Slider Plate with cam lever
- 4 - pucks
- 4 - 8mm Button Head Screws
- 4 - 1.5” diameter aluminum washer
- 4 - M8 x 60 SS flat head screws
- 2 - short spacers
- 2 - long spacers

go to backroadequipment.com for installation instructions

**Do not exceed the OEMs
recommendation for weight on the
rear rack of the motorcycle!!**

In order to properly locate the top box
it will be necessary to install, remove
and re-install the BRE rack, please keep
this in mind and read through the
instructions completely before starting
the work.

Step 1 Remove the 2 plastic caps on the rear of the grab handles.


Step 2 Remove the 4 OEM T45 screws (2 inside the grab handles and the 2 to the rear).

Step 3 Install the BRE short aluminum spacer into the grab handle holes (large diameter faces upward).

Step 4 Install the BRE long spacers into the rear pockets (large diameter faces upward).

Step 5 Place the Slider rack over the spacers and install the 4 BRE M8 x 60 flat head screws. Hand start all 4 screws.

Step 6 Torque the 4 BRE M8 screws to 18ftlbs.



Step 7 Install one of the black plastic pucks into the key hole with the cam lever. Lock the puck into place with the cam lever. This will be referred to as the “Master Puck”

Note: Remove the large washer and screw from the puck before putting into the plate. The screws and washers are installed into the pucks for shipment as part of our QA process.



Step 8 Insert the 3 remaining pucks into the keyholes in the plate.



Step 9 Position the box on top of the pucks. Determine the for/aft location (side to side will be determined later). Position the box as far forward as possible without interfering with passenger comfort. Also consider if you will be placing any gear on the seat or if you want to be able to remove the seat with the box in place. Use a marker to mark the master puck location on the box.



Step 10 Place the box on a table or other work surface. Remove the 4 flat head screws and nuts holding the Slider plate onto the motorcycle.

Place the rack on the underneath side of the box.



Step 11 Locate the puck marker on the box and align the master puck up with the mark as it was on the bike. Adjust the box side to side and make any final adjustments to the location.



Step 12 Make certain the plate is positioned on the box where you would like it. A helping hand would be useful during the next few steps but it can be done solo.

With a 1/4" drill bit and electric drill use the master puck as a drill guide and drill a pilot hole through the box.



Step 13 Remove the rack from the box. Use the 21/64” drill bit and electric drill to enlarge the 1/4” pilot hole



Step 14 Use the 5/16” button head cap screw and 1 ½” aluminum washer to attach the master puck to the box.



Step 15 Place the rack with the other 3 pucks onto the master puck and latch it into position. Square up the plate and box to each other (last chance).



Step 16 With the ¼” drill bit, use the puck diagonally across from the master puck as a drill guide and drill a second pilot hole in the box.

Make sure the pucks are seated in the keyholes before drilling!!



Step 17 Remove the rack from the box. Use the $21/64$ " drill bit and electric drill to enlarge the $1/4$ " pilot hole




Step 18 Bolt the second puck to the box. Place the rack on the box and latch it into position. With the ¼” drill bit use the 2 remaining pucks as drill guides and drill the last 2 pilot holes.

Make sure the pucks are seated in the keyholes before drilling!!



Step 19 Remove the rack and pucks from the box. Use the 21/64" drill bit and electric drill to enlarge the last two 1/4" pilot holes.



Step 20 Install all pucks onto the box using the 1 ½” aluminum washers and 5/16” button head cap screws.

Lightly snug the puck screws at this time, later they will be fully tightened.

Step 21 Re-install the Slider plate on the motorcycle, verify the spacers are in place. Re-install the M8 flat head screws and lock nuts, torque to 18 ftlbs.



Step 22 Install the box onto rack and latch it into place with the cam lever.



Step 23 Torque the puck screws to 108 in. lbs.



That completes the installation process. Test ride the motorcycle and then check all the fasteners for tightness. Also check the fasteners again after 1000 miles and at every oil change after that.

For security a 3/16” pad lock can be used to lock the cam lever in the closed position.

Thank You

